



# KSP

Killeen Security Products  
[www.iccore.com](http://www.iccore.com)

## Cam Installation for Housings w/Screw-On Nest



### Instructions:

K series cams are installed as shown in the above image. Screws with pre-applied thread lock need to be used to ensure proper function. If screws are removed, a suitable thread lock product must be re-applied or use new screws with the pre-applied thread lock patch as provided by KSP. A housing installation tool does a good job of holding the drive assembly while tightening cam screws.

33 Hermon Street  
Worcester MA 01610

Phone: 1-800-577-5397  
Fax: 1-508-753-2183  
E-mail: [sales@iccore.com](mailto:sales@iccore.com)